The Focus Indicator Focus status is shown by the focus indicator. Focus indicator () Camera focusing. (lights green) Subject in focus; focus locked (focus mode). Subject in focus (focus mode). Subject in focus (focus mode). Focus is automatically adjusted for changes in distance to subject. (blinks white) Camera unable to focus. Manual focus (focus mode).