## LENS ZOOM/FOCUS SETTING

Adjust settings for compatible lenses with focus rings or power zoom.

## FOCUS RING ROTATE

Choose the direction in which the focus ring is rotated to increase the focus distance.

Options					
<b>○ CW</b> (clockwise)	<b>♦ CCW</b> (counterclockwise)				

## FOCUS RING OPERATION

Choose how the camera adjusts focus in response to the movement of the focus ring.

Option	Description					
NONLINEAR	Focus is adjusted at the same rate as the ring is rotated.					
	Focus is adjusted linearly according to the amount the ring is rotated, but the focusing speed is unaffected by the speed the ring is rotated.					

## ME CONSTANT SPEED FOCUS (Fn)

Choose the rate at which the focus distance changes when adjusted using function buttons during manual focus with compatible power zoom lenses. The higher the number, the higher the rate.

Options									
1(SLOW)	2	3	4	5	6	7	8(FAST)		