## **W** WHITE BALANCE

Options are the same as those for still photography, but settings must be adjusted separately (126).

## **M** DYNAMIC RANGE

Choose a dynamic range for movie recording.

Option	Description
₽ <mark>100</mark> 100%	
R200 200%	See "DYNAMIC RANGE" (🕮 130).
R400 400%	



- ♦ AUTO (automatic dynamic range control) is not available during movie recording.
  - 1200 200% is available at sensitivities of from ISO 250 to ISO 12800. **400 400%** at sensitivities of from ISO 500 to 12800.
  - This item is available when The is selected for MOVIE **SETTING** > **F-Log/HLG RECORDING**.

## TONE CURVE

Options are the same as those for still photography, but settings must be adjusted separately (1991).

## COLOR

Options are the same as those for still photography, but settings must be adjusted separately (1131).