Assigning Roles to the Function Buttons

Pressing and holding the DISP/BACK button displays a dialog where you can choose the roles assigned to the function buttons.

1 Press and hold the DISP/BACK button until a control selection menu is displayed.





Nou can also assign roles to function buttons using **EBUTTON DIAL SETTING > FUNCTION (Fn) SETTING.**

- 2 Highlight the desired control and press MENU/OK.
- 3 Highlight any of the following options and press MENU/OK to assign it to the selected control.

Roles That Can Be Assigned to the Function Buttons

Choose from:

- ₩HEN SETTO M (ON/OFF SWITCH)
 FOCUS MODE
- IMAGE SIZE
- IMAGE OUALITY
- RAW
- FILM SIMULATION
- GRAIN FFFFCT
- COLOR CHROME FEFECT
- COLOR CHROME EX BLUE
- DYNAMIC RANGE
- D RANGE PRIORITY
- WHITE BALANCE
- CLARITY
- RECALL CUSTOM 1 SETTING
- FOCUS AREA
- FOCUS CHECK

- AF MODE
- AF-C CUSTOM SETTINGS
- FACE DETECTION ON/OFF
- RIGHT/I FFT FYF SWITCH
- SUBJECT DETECTION ON/OFF
- AF RANGE LIMITER
- FOCUS CHECK LOCK
- SPORTS FINDER MODE
- PRF-SHOT FS ₽
- SFI F-TIMFR
- AF BKT SFTTING
- FOCUS BKT SETTING
- PHOTOMETRY
- SHUTTER TYPE