Connecting by scanning a QR code

- Select INFORMATION > HARDWARE INFO in the network/ USB setting menu. A QR code is displayed.
- 2 Launch the camera application on the tablet and scan the QR code.

The web browser launches, and the remote recording display appears.

Connecting a second or subsequent camera

Either enter the IP address in the remote recording display in the web browser or scan the QR code to connect.

When you connect a second or subsequent camera, set the same **SERVER TYPE** as the first camera beforehand (■ 298).

Connecting using an IP address

- 1 Select INFORMATION > HARDWARE INFO in the network/ USB setting menu. The IP address of the camera is displayed.
- 2 Click or tap the thumbnail of the + mark in the "Choose camera" area of the remote recording display.



3 An entry screen appears. Enter the camera's IP address and an account name and password.
The second appears of the large time and password.

The remote recording display will appear in the browser.

