

Default	
① SHOOTING MODE	⑤ ♯ FILM SIMULATION
② S.S. (MOVIE OPTIMIZED	⑥ ISO (MOVIE OPTIMIZED
CONTROL ← ►)	CONTROL ← ►)
3 MOVIE MODE RESOLUTION/	① MOVIE MODE FRAME RATE
ASPECT RATIO	
④ ₩ WHITE BALANCE	
	TEMP. (WHEN K SELECTED)

The quick menu shows the options currently selected for items (2)–(8), which can be changed.