PLAYBACK

Option	Description					
	Putting your eye to the viewfinder turns the viewfinder					
SENSOR EYE SENSOR	on and the LCD monitor off; taking your eye away turns					
	the viewfinder off and LCD monitor on.					
₽ VF VIEWFINDER ONLY	Viewfinder on, LCD monitor off.					
dco LCD ONLY	LCD monitor on, viewfinder off.					

EVF BRIGHTNESS

Adjust the brightness of the display in the electronic viewfinder.

Option	Description							
AUTO	Automatic brightness adjustment.							
ΜΔΝΙΙΔΙ	Adjust brightness manually; choose from options between –7 and +5.							

EVF COLOR

Adjust the hue of the display in the electronic viewfinder.

Options											
-5	-4	-3	-2	-1	0	+1	+2	+3	+4	+5	

EVF COLOR ADJUSTMENT

Adjust the color of the display in the electronic viewfinder.

1 Adjust colors using the focus stick (focus lever).



2 Press MENU/OK.