1	Flash (TTL) mode	263	25	Exposure compensation	81
2	Out-of-frame indicators	259	26	Aperture	57, 62, 63
3	Flash compensation	263		Distance indicator ²	
4	Boost mode	231	28	Shutter speed	57, 58, 63
(5)	Control lock ³	230	29	TTL lock	153, 223, 254
6	Sound and flash indicator	203	30	AE lock	84, 228
7	ND (Neutral Density) filter indica	tor 150	31)	Metering	79
8	Depth-of-field preview	62, 75	32	Shooting mode	56
9	Conversion lens	150	33	Focus mode ²	66
10	Digital teleconverter	150	34	Focus indicator ²	67
11)	Location data download status	241, 274	35	Manual focus indicator ²	66, 73
12	Sports finder mode	138	36	AF lock	84, 228
13)	Bluetooth ON/OFF	236	37	Histogram	22
14)	Image transfer status	236, 274	38	Dynamic range	113
(15)	Number of available frames 1	317		D-range priority	
16)	Image size	104	40	Film simulation	106
17)	Image quality	105	41)	White balance	110
18)	Battery level	39	42	AWB lock	228
19	External power source in use	37	43	Exposure indicator	63, 81
20	Bright frame	45	44)	AF+MF indicator ²	130
21)	Virtual horizon	22	45	Shutter type	147
22	Temperature warning	316	46	Continuous mode	89
23	Focus frame			Self-timer indicator	
(24)	Concitivity	77			

¹ Shows "9999" if there is space for over 9999 frames.

² Not displayed when **ON** is selected for **☑ SCREEN SET-UP** > **LARGE INDICATORS MODE(EVF/OVF)**.

³ Displayed when controls have been locked by pressing and holding the **MENU/OK** button. Control lock can be ended by pressing and holding the **MENU/OK** button again.