TIME CODE SETTING (Movie Recording)	216
TIME CODE DISPLAY	216
START TIME SETTING	216
COUNT UP SETTING	217
DROP FRAME	217
HDMI TIME CODE OUTPUT	218
Playback and the Playback Menu	219
The Playback Display	220
The DISP/BACK Button	
Viewing Pictures	
Playback Zoom	
Multi-Frame Playback	
The Playback Menu	
SWITCH SLOT	
RAW CONVERSION	
HEIF TO JPEG/TIFF CONVERSION	229
ERASE	230
SIMULTANEOUS DELETE	232
CROP	232
RESIZE	233
PROTECT	234
IMAGE ROTATE	
VOICE MEMO SETTING	
RATING	
COPY	
TRANSFER IMAGE TO SMARTPHONE	
★ WIRELESS COMMUNICATION	
SLIDE SHOW	
PHOTOBOOK ASSIST	
PRINT ORDER (DPOF)	
instax PRINTER PRINT	
DISP ASPECT	246
Network/USB Features and Settings	247
Overview	248
Supported Features	248