Supplied Accessories

The following are included with the camera:

- NP-W235 rechargeable battery
 - Tor reasons of safety, the battery is not charged at shipment. The camera will not function if the battery is not charged; be sure to charge the battery before use (\$\equiv 37)\$.
- AC-5VJ AC power adapter
- Plug adapter
- USB cable (approx. 0.6 m/2 ft.)
- Body cap (comes attached to camera)
- Shoulder strap
- Cooling fan connector cover (comes attached to camera)
- If you purchased a lens kit, check that a lens is included.
 - The plug adapter supplied varies with the country or region.
 - For information on compatible computer software, see "Software for Use with Your Camera" (352).