
5 Choose whether to use a proxy server.

In this case we'll choose **DISABLE**.

- Choose **ENABLE** to enter the address and port number for a proxy server.
- 6 Choose whether to enable PASV mode.





- 7 Select USER NAME & PASSWORD. Enter the user name and password used for login to the FTP server.

 - For connection to servers that do not require a user name and password, select **ANONYMOUS**
 - Selecting FTPS for FTP SERVER TYPE lets you choose the authentication method. If desired, you can load a self-signed root certificate using FTP OPTIONAL SETTING > ROOT CERTIFICATE.



- R Choose the destination folder.
 - Choose ROOT FOLDER to upload pictures to the server's root directory.
 - To select a different folder, choose SPECIFY FOLDER.

