## Assigning Roles to the Lens Function Buttons

The roles played by the lens function buttons can be selected using the BUTTON/DIAL SETTING > POWER ZOOM LENS FUNCTION (Fn) SETTING option in the setup menu.

- ■ WHEN SETTO M (ON/OFF SWITCH) FLICKER REDUCTION
- IMAGE SIZE
- IMAGE OUALITY
- RAW
- FILM SIMULATION
- GRAIN FFFFCT
- COLOR CHROME FEFECT
- COLOR CHROME FX BLUE
- DYNAMIC RANGE
- D RANGE PRIORITY
- WHITE BALANCE
- CLARITY
- RECALL CUSTOM 1 SETTING
- FOCUS AREA
- FOCUS CHECK
- FOCUS MODE
- AF MODE
- AF-C CUSTOM SETTINGS
- FACE DETECTION ON/OFF
- RIGHT/I FFT FYF SWITCH
- SUBJECT DETECTION ON/OFF
- AF RANGE I IMITER
- FOCUS CHECK LOCK
- SPORTS FINDER MODE
- PRE-SHOT **ES ₽**
- SFI F-TIMFR
- AF BKT SFTTING
- FOCUS BKT SETTING
- PHOTOMETRY
- SHUTTER TYPE

- FLICKERI ESS S.S. SETTING.
- ISO
- IS MODE
- WIRFLESS COMMUNICATION
- FLASH COMPENSATION
  - FLASH FUNCTION SETTING
  - TTI-I OCK
  - MODELING FLASH
- MOVIE RECORDING RELEASE
  - HIGH SPEED REC
  - SFI F-TIMFR
- BACKGROUND DEFOCUS MODE
  - FIX MOVIF CROP MAGNIFICATION
  - S MODE BOOST
- PRODUCT PRIORITY MODE
- 7FBRA SETTING
  - COOLING FAN SETTING
  - INTERNAL/EXTERNAL MIC LEVEL ADJUSTMENT
- 4ch AUDIO PLAYBACK
  - MOVIE OPTIMIZED CONTROL
  - VIEW MODE SETTING
  - PREVIEW DEPTH OF FIELD
    - PREVIEW EXP/WB IN MANUAL MODE
    - NATURAL LIVE VIEW
    - HISTOGRAM
  - FLECTRONIC LEVEL SWITCH
    - LARGE INDICATORS MODE
      - F-Log VIEW ASSIST