## INTERVAL PRIORITY MODE

If ON is selected, the camera will adjust shutter speed during interval-timer photography to ensure that exposures are not longer than the interval between photographs.

Options	
ON	OFF

This option takes effect only when the camera selects the shutter speed automatically.

## FLICKER REDUCTION

Reduce flicker in pictures and the display when shooting under fluorescent lighting and other similar light sources.

Option	Description
	Flicker reduction is applied to all frames continuous
	shooting frame rate reduces.
	Flicker measurement is taken prior to the first frame only
	and the same reduction amount is applied to all subse-
	quent frames that flicker may occur.
OFF	Flicker reduction disabled.



- Flicker reduction increases the time needed to record pictures.
  - OFF is selected for FLICKER REDUCTION when the electronic shutter is used.
  - Flicker reduction is not available during movie recording.