


SCREEN SETTING

Make changes to display settings.

To access display settings, press MENU/OK, select the ☑ (SET UP) tab, and choose SCREEN SET-UP.



VIEW MODE SETTING

Adjust settings for eye sensor, EVF (electronic viewfinder), or LCD monitor view modes (🗎 14).

EVF BRIGHTNESS

Adjust the brightness of the display in the electronic viewfinder.

Option	Description
AUTO	Automatic brightness adjustment.
MANUAL	Adjust brightness manually; choose from options between –7 and +5.

EVF COLOR

Adjust the hue of the display in the electronic viewfinder.

