
The Playback Display

This section lists the indicators that may be displayed during playback.





	20 20 10 10 10 10 10 10 10 10 10 10 10 10 10
1 Date and time43, 45, 271	20 White balance
2 Location data305	21 Sensitivity104
3 Frame-number display	22 Exposure compensation 107
Bluetooth ON/OFF	23 Aperture72, 75, 77
5 Image transfer order	24 Time code217
6 Image transfer status	25 Shutter speed
7 Number of frames selected for upload	26 Playback mode indicator50
8 Protected image233	27 Movie icon63
9 Bluetooth host247	28 Four-channel (quadrophonic) audio
(10) Frame number	184, 216
(11) Low battery42	29 HDR image116
(12) Image quality	30 Red-eye removal indicator 178
(13) Movie mode	31) Filter81
131	32) Photobook assist indicator240
(15) Image size128	33 DPOF print indicator242
16 Film format191	34 Voice memo
7 Film simulation	35 Rating236
18 Dynamic range140	36 Gift image50
(19) HDR116	37) Face detection indicator156