MF ASSIST

Choose how focus is displayed in manual focus mode.

Option	Description
STANDARD	Focus is displayed normally (focus peaking, digital split image, and
	digital microprism are not available).
DIGITAL SPLIT IMAGE	Displays a black-and-white (MONOCHROME) or color (COLOR)
	split image in the center of the frame. Frame the subject in the
	split-image area and rotate the focus ring until the four parts of
	the split image are correctly aligned.
DIGITAL MICROPRISM	A grid pattern that emphasizes blur is displayed when the subject
	is out of focus, disappearing to be replaced by a sharp image when
	the subject is in focus.
FOCUS PEAK	The camera heightens high-contrast outlines. Choose a color and
HIGHLIGHT	peaking level.



You can also choose MF assist options by holding the center of the rear command dial

FOCUS CHECK

If ON is selected, the display will automatically zoom in on the selected focus area when the focus ring is rotated in manual focus mode.

Options			
ON	OFF		



- Pressing the center of the rear command dial cancels focus zoom.
 - The zoom position is centered on the current focus area and changes when the focus area is changed.