3 Rotate the shutter speed dial to A.



AUTO will appear in the display.



4 Rotate the sensitivity dial to A.



5 Rotate the focus mode selector to C.



- ① To use the shutter speed and sensitivity dials, press the dial lock release and rotate the dial to the desired setting.
- These settings can also be adjusted using touch controls (🕮 28).