## **IS MODE**

This item is also found in the movie menus (\$\equiv 197\$). Changes here also apply to the item in the movie menus.

#### **SE IS MODE BOOST**

This item is also found in the movie menus (1971). Changes here also apply to the item in the movie menus.

#### **AUDIO SETTING**

Adjust audio-related settings for movie recording.

# INTERNAL MIC LEVEL ADJUSTMENT

Adjust the recording level for the built-in microphone.

Option	Description
AUTO	The camera adjusts the recording level automatically.
MANUAL	Adjust the recording level manually. Choose from 25 recording levels.
OFF	Turn the built-in microphone off.

### EXTERNAL MIC LEVEL ADJUSTMENT

Adjust the recording level for external microphones.

Option	Description
AUTO	The camera adjusts the recording level automatically.
MANUAL	Adjust the recording level manually. Choose from 25 recording levels.
OFF	Disable recording using external microphones.