## Saving Current Settings

Save current settings in a custom settings bank.

- Navigate to MIMAGE QUALITY SETTING in the photo menus, highlight EDIT/SAVE CUSTOM SETTING, and press MENU/OK.
  - To save settings for movie recording, navigate to 

    MOVIE SETTING in the movie menus and select 

    EDIT/SAVE CUSTOM SETTING.
- 2 Highlight a destination bank for current settings (C1 through C4) and press MENU/OK.



3 Highlight SAVE CURRENT SETTINGS and press MENU/OK.



4 Highlight OK and press MENU/OK. Current settings will be saved to the selected bank.

