EDIT/SAVE CUSTOM SETTING

Save up to 7 sets of custom camera settings for commonly-encountered situations. Saved settings can be recalled using **MAGE OUALITY SETTING** > **SELECT CUSTOM SETTING**.

- 1 Select MIMAGE QUALITY SETTING in the shooting menu, then highlight EDIT/SAVE CUSTOM SETTING and press MENU/OK.
- 2 Highlight a custom settings bank and press MENU/OK to select.



3 Highlight EDIT and press MENU/OK.
A list of shooting menu options will be displayed.



- To store current camera settings in the selected bank, highlight **SAVE CURRENT SETTINGS** and press **MENU/OK**.
 - To restore default settings for the current bank, select **RESET**.
 - Banks can be renamed using **EDIT CUSTOM NAME**.
- 4 Highlight an item you wish to store in the custom settings bank and press MENU/OK.

Adjust settings for the selected item.

