_		
۶	BUTTON/DIAL SETTING	
1/3	FOCUS LEVER SETTING	294
	EDIT/SAVE QUICK MENU	295
	EDIT/SAVE QUICK MENU	295
	FUNCTION (Fn) SETTING	295
	POWER ZOOM LENS FUNCTION (Fn) SETTING	295
	SELECTOR BUTTON SETTING	295
	COMMAND DIAL SETTING	296
	S.S OPERATION	297
2 ⁄3	COMMAND DIAL DIRECTION	297
	SHUTTER AF	298
	SHUTTER AE	298
	SHOOT WITHOUT LENS	299
	SHOOT WITHOUT CARD	299
	LENS ZOOM/FOCUS SETTING	300
	AE/AF-LOCK MODE	302
	AWB-LOCK MODE	302
3 ∕₃	APERTURE RING SETTING (A)	303
	APERTURE SETTING	303
	► Fn1 BUTTON SETTING	303
	TOUCH SCREEN SETTING	304
	LOCK	305

₽ POWER MANAGEMENT	
AUTO POWER OFF	306
PERFORMANCE	306
EVF/LCD BOOST SETTING	307
AUTO POWER OFF TEMP.	307
SAVE DATA SETTING	
FRAME NO.	308
EDIT FILE NAME	309
CARD SLOT SETTING	309
SELECT SLOT(♣ SEQUENTIAL)	309
SELECT FOLDER	310
COPYRIGHT INFO	310
GEOTAGGING	310