## MOUNT ADAPTER SETTING

Adjust settings for lenses attached via a mount adapter. The camera can store settings for multiple lenses (LENS 1 through LENS 6).



Any changes made using this item also apply in movie mode (#167).

## Choosing a Focal Length

Enter the lens's true focal length.



## Distortion Correction


Choose from STRONG, MEDIUM, WEAK options to correct BARREL or **PINCUSHION** distortion.



## Color Shading Correction

Color (shading) variations between the center and edges of the frame can be adjusted separately for each corner.

To use color shading correction, follow the steps below.



1 Rotate the front command dial to choose a corner. The selected corner is indicated by a triangle.