HDR

Each time the shutter button is pressed, the camera takes three shots, varying exposure each time, and combines them into a single picture. The resulting photograph preserves details in highlights and shadows.

1 Rotate the drive dial to HDR.



2 Navigate to DRIVE SETTING > HDR MODE in the ■ SHOOTING SETTING menu and choose the amount the brightnesses of the exposures vary (■ 166).

Option	Description
AUTO	Dynamic range is automatically set to a value of from 200%
	to 800%.
200%	Dynamic range is set to 200%.
400%	Dynamic range is set to 400%.
800%	Dynamic range is set to 800%.
800% +	Camera settings are adjusted for maximum variation in dy-
	namic range.

3 Take photographs.
The camera will create a combined image.