## SPORTS FINDER MODE

Take pictures using the crop in the center of the display. Choose this option for pictures of athletes, birds, and other moving subjects.



Option	Description
ON	Pictures are taken using a 1.29× crop, reducing the picture angle by an amount equivalent to increasing lens focal length by 1.29×; the crop is shown by a frame in the display.
OFF	The 1.29× crop is disabled.



- The 
  IMAGE QUALITY SETTING > IMAGE SIZE item in the shooting menu is fixed at M.
  - The sports finder is not available in modes that offer an electronic shutter.