## Exposure Preview-

To preview exposure in the LCD monitor, select **PREVIEW EXP./WB** for

## SCREEN SET-UP > PREVIEW EXP./WB IN MANUAL MODE.





Select an option other than **PREVIEW EXP./WB** when using the flash or on other occasions on which exposure may change when the picture is taken.