EF-X8

The following settings are available when an optional EF-X8 shoe-mounted flash unit is attached.



| Setting | Description |
|------------------------------|---|
| 1 Flash control mode | Choose from the following options: • TTL: TTL mode. Adjust flash compensation (②) and choose a flash mode (③). • M: The flash fires at the selected output (②) regardless of subject brightness or camera settings. Output is expressed in fractions of full power, from ½ to ½4. The desired results may not be achieved at low values if they exceed the limits of the flash control system; take a test shot and check the results. • Æ (primary flash): Choose if the flash is being used as a primary flash controlling secondly flash units, for example as part of a studio flash system. • ④OFF (OFF): The EF-X8 does not fire. |
| 2 Flash compensation/ output | Adjust flash level. The options available vary with the flash control mode $(\widehat{1})$. |