4 Check the time.

When pairing is complete, you will be prompted to set the camera clock to the time reported by the smartphone or tablet. Check that the time is correct.



- To set the clock manually, press DISP/BACK (1 39).
- 5 Synchronize the camera settings with the settings configured on your smartphone or tablet.



- The option selected can be changed at any time using CONNECTION SETTING > Bluetooth SETTINGS.
- 6 Set the clock.
 Press MENU/OK to set the camera clock to the time reported by the smartphone or tablet and exit to shooting mode.
- 7 Format the memory card (208).
 - Format memory cards before first use, and be sure to reformat all memory cards after using them in a computer or other device.
- If the battery is removed for an extended period, the camera clock will be reset and the language-selection dialog will be displayed when the camera is turned on.

Skipping the Current Step-

If you skip a step, a confirmation dialog will be displayed; select **NO** to avoid repeating any steps you skipped the next time the camera is turned on.