

## **Network/USB Setting Menus**

Adjust camera network and USB settings.

To access network/USB settings from the shooting or playback display, press **MENU/OK** and select the (network/USB setting) tab.



## CREATE/EDIT CONNECTION SETTING

Create or edit connection setting profiles.

## CREATE USING WIZARD

Choose network/USB and communication settings for a connection setting profile.

 Select CREATE/EDIT CONNECTION SETTING > CREATE USING WIZARD in the network/USB setting menu.

