2 Follow the on-screen instructions to ready the wireless LAN router.

SIMPLE SETUP

PUSH ⚡WPS BUTTON ON
Wi-Fi ROUTER UNTIL LAMP ON
Wi-Fi ROUTER STARTS FLASHING

CONNECT BY PIN CODE
CANCEL

- You also have the option of connecting using a PIN. Display the camera PIN by pressing the focus stick (focus lever) up and enter it on the wireless LAN router.

3 Press **MENU/OK** when setup is complete.

MANUAL SETUP
AP001234567
REGISTRATION COMPLETED
**FUJIFILM-T100-1234**

END

Connecting Using an IP Address

Connect to a computer for tethered photography using a manually-created network/USB setting profile giving the IP address and other network settings.

1 Select **MANUAL**.

- Select **AUTO** to assign the camera an IP address automatically.

WIRELESS L...

ACCESS P...
IP ADDRESS   AUTO
NEXT   MANUAL

2 Enter an IP address.

IP ADDRESS SETTING

IP ADDRESS
SUBNET MASK
GATEWAY ADDRESS
DNS SERVER ADDRESS

Network/USB Setting Menus

8

265