ISO AUTO SETTING

Choose the base sensitivity, maximum sensitivity, and minimum shutter speed for use when ISO sensitivity is set to **A** (auto). Settings for **AUTO1**, **AUTO2**, and **AUTO3** can be stored separately (1997).

DIGITAL TELE-CONV.

Zoom in on your subject during shooting using ultra-high-resolution digital zoom.

Option	Description
	Take pictures using 2× zoom. ■- and M-size pictures
	are automatically cropped to size 🛐.
	Take pictures using 1.4× zoom. 🔲 -size pictures are auto-
	matically cropped to size $lacktriangle$.
OFF	Digital teleconverter off.

- Image quality may drop when the digital teleconverter is used.
- The digital teleconverter cannot be used when a 1.29x crop is selected during burst photography or when **ON** is selected for **SPORTS FINDER MODE**.