RATING

Rate pictures using stars.

- 1 Select RATING in the playback menu.
- 2 Rotate the front command dial to choose a picture and the rear command dial to choose a rating of from 0 to 5 stars ("★").
- The focus stick (focus lever) can be used in place of the front command dial to choose a picture.
 - The rating dialog can also be displayed by pressing the AEL/AFL button in single-frame, nine-frame, or hundred-frame playback.
 - Use touch controls to zoom in or out.