The Setup Menus	269
USER SETTING	270
FORMAT	270
♠ AREA SETTING	271
DATE/TIME	271
TIME DIFFERENCE	272
₹9 言語/LANG	
▲ MY MENU SETTING	
₩ MY MENU SETTING	273
SENSOR CLEANING	273
BATTERY AGE	
SOUND & FLASH	274
RESET	274
REGULATORY	274
SOUND SETTING	275
AF BEEP VOL	275
SELF-TIMER BEEP VOL.	
OPERATION VOL.	
REC START/STOP VOLUME	
MS ELECTRONIC SHUTTER VOLUME	
MS ELECTRONIC SHUTTER SOUND	
ES ELECTRONIC SHUTTER VOLUME	
ES ELECTRONIC SHUTTER SOUND	
PLAYBACK VOLUME	
4ch AUDIO PLAYBACK	
SCREEN SETTING	
VIEW MODE SETTING	
EVF BRIGHTNESS	= -
EVF COLOR	
EVF COLOR ADJUSTMENT	
LCD BRIGHTNESS	
LCD COLOR	
LCD COLOR ADJUSTMENT	279