Roles That Can Be Assigned to Touch Function Gestures

Choose from:

- IMAGE SIZE
- IMAGE QUALITY
- RAW
- FII M SIMULATION
- GRAIN FFFFCT
- COLOR CHROME FEFECT
- COLOR CHROME EX BLUE
- SMOOTH SKIN FFFFCT
- DYNAMIC RANGE
- D RANGE PRIORITY
- WHITE BALANCE
- CLARITY
- SELECT CUSTOM SETTING
- RECALL CUSTOM 1 SETTING
- FOCUS AREA
- FOCUS CHECK
- AF MODE
- AF-C CUSTOM SETTINGS
- FACE DETECTION ON/OFF
- RIGHT/I FFT FYF SWITCH
- SUBJECT DETECTION ON/OFF
- AF RANGE I IMITER
- FOCUS CHECK LOCK
- DRIVE SETTING
- SPORTS FINDER MODE
- PRE-SHOT **ES**
- SFI F-TIMER
- PHOTOMETRY
- SHUTTER TYPE
- FLICKER REDUCTION
- FLICKERI ESS S S SETTING
- ISO AUTO SETTING
- IS MODE

- DIGITAL TELE-CONV.
- MUITI EXPOSURE
- WIRFLESS COMMUNICATION
- FLASH FUNCTION SETTING
- TTI-LOCK
- MODELING FLASH
- HIGH SPFFD RFC
- SFI F-TIMER
 - FIX MOVIE CROP MAGNIFICATION
- S MODE BOOST
- 7FBRA SETTING
 - INTERNAL/EXTERNAL MICLEVEL ADJUSTMENT
- 4ch AUDIO PI AYBACK
- MOVIF OPTIMIZED CONTROL
- VIFW MODE SETTING
 - PREVIEW DEPTH OF FIELD
 - PREVIEW EXP/WB IN MANUAL MODE
- NATURAL LIVE VIEW
 - HISTOGRAM
 - FLECTRONIC LEVEL SWITCH
 - I ARGE INDICATORS MODE
 - F-Log VIEW ASSIST
 - 700M/FOCUS CONTROL RING
- APERTURE SETTING
- LOCK SETTING
- PERFORMANCE
- AUTO IMAGE TRANSFER ORDER
- Bluetooth ON/OFF
- OUICK MENU
- PLAYBACK
 - NONF



To disable touch-function gestures, choose **NONE**.