<b>6</b>	D
Setting	Description
<b>7</b> Flash mode (TTL)	Choose a flash mode for TTL flash control. The options available vary with the shooting mode ( <b>P, S, A</b> , or <b>M</b> ) selected.  • XTL (FLASH AUTO): The flash fires only as required; flash level is adjusted according to subject brightness.
	level is adjusted according to subject brightness. A icon displayed when the shutter button is pressed halfway indicates that the flash will fire when the photo is taken.
	• \$TTL (STANDARD): The flash fires with every shot if possible; flash level is adjusted according to subject brightness. The flash will not fire if not fully charged when the shutter is released.
	• \$\text{3LW (SLOW SYNC.)}: Combine the flash with slow shutter speeds when photographing portrait subjects against a backdrop of night scenery. The flash will not fire if not fully charged when the shutter is released.
<b>8</b> Sync	Control flash timing.
	• nor (1ST CURTAIN): The flash fires immediately after the shutter opens (generally the best choice).
	<ul> <li>RÉAR (2ND CURTAIN): The flash fires immediately before the shutter closes.</li> </ul>
<b>9</b> Zoom	The angle of illumination (flash coverage) for units that support flash zoom. Some units allow the adjustment to
	be made from the camera. Select <b>AUTO</b> to automatically match coverage to focal length when using optional conversion lenses.