
## WAVEFORM/VECTORSCOPE

Choose whether to display chrominance and luminance signals during movie recording. The position and size can be changed using the focus stick (focus lever) and command dials.

Options			
WAVEFORM	PARADE	VECTORSCOPE	OFF

## WAVEFORM

A waveform is displayed.



## PARADE

An RGB parade is displayed. You can change the display method for colors by turning the front command dial.

