Selecting a Menu Tab

To navigate the menus:

1 Press MENU/OK to display the menus.





2 Press the selector left to highlight the tab for the current menu.



- 3 Press the selector up or down to highlight the tab containing the desired item.
- 4 Press the selector right to place the cursor in the menu.
- Use the front command dial to select menu tabs or page through menus and the rear command dial to highlight menu items.