COUNT UP SETTING

Choose whether time is clocked continuously or only during movie recording.

Option	Description
REC RUN	Time is clocked only during movie recording.
FREE RUN	Time is clocked continuously.

DROP FRAME

At frame rates of 59.94P, and 29.97P, a discrepancy will gradually develop between the time code (measured in seconds) and the actual recording time (measured in fractions of a second). Choose whether the camera drops frames as necessary to match the recording time to the time code.

Option	Description
	The camera drops frames as necessary to maintain a strict
	match between the time code and the actual recording time.
OFF	Frames are not dropped.



The time code display varies with the option selected.





• Selecting a frame rate of 23.98P disables frame drop.