MOUNT ADAPTOR SETTING

Adjust settings for lenses attached via a mount adapter.



Any changes made using this item also apply in movie mode (#197).

Shutter Select

When using lenses with an internal shutter, choose whether to use the shutter on the camera (BODY) or the lens (LENS).



This option may have no effect with some lenses.

Saved Settings

Store settings for up to 6 lenses, or choose OFF to disable corrections for focal length, distortion, color shading, and peripheral illumination.

Choosing a Focal Length

Use the focus stick (focus lever) to enter the focal length.



Distortion Correction

Choose from STRONG, MEDIUM. WEAK options to correct BARREL or **PINCUSHION** distortion.

