• Select **GATEWAY ADDRESS** and enter a gateway address.



 Select DNS SERVER ADDRESS and enter a DNS server address.



-Connection Status-

The status of the connection to Frame.io is shown by an icon in the electronic viewfinder or LCD monitor.



lcon	Connection status
))ı· frame.io (white)	Connected to Frame.io.
)))· frame.io (amber)	Camera has temporarily suspended upload to Frame.io. To resume, select Frame.io Camera to Cloud > UPLOAD SETTING > TRANSFER/SUSPEND > TRANSFER.
))ı· frame.io (gray)	Not connected to Frame.io.
*	Frame.io server has set camera status to "paused". To restore connection, clear "paused" status using computer or other device.