2 Highlight the source bank and press MENU/OK.



3 Highlight COPY and press MENU/OK.



- 4 Highlight the destination bank (C1 through C6) and press MENU/OK.
 A confirmation dialog will be displayed.
 - Any changes to custom settings in the destination bank will be overwritten.
- 5 Highlight OK and press MENU/OK. The selected settings will be copied to the destination bank, overwriting any existing settings.



