N If **DISABLE** is selected for **IMAGE QUALITY SETTING** > **AUTO UPDATE CUSTOM SETTING** in the photo menu or for **MOVIE SETTING** > **AUTO UPDATE CUSTOM SETTING** in the movie menu, red dots will appear next to the edited items but the changes will not be saved automatically.

• To save the changes for selected items, highlight the items in the list and press **Q**.

• To save changes for all items, return to Step 3 and select **SAVE THE CHANGES**. To cancel all changes and restore the previous settings, select **RESET THE CHANGES.**

• If you copy an item marked by a red dot, the item will be copied with the changes intact.