COLOR SHADING CORRECTION

Color (shading) variations between the center and edges of the frame can be adjusted separately for each corner.

To use color shading correction, follow the steps below.



- 1 Rotate the rear command dial to choose a corner. The selected corner is indicated by a triangle.
- 2 Use the selector to adjust shading until there is no visible difference in color between the selected corner and the center of the image.
 - Press the selector left or right to adjust colors on the cyanred axis.
 - Press the selector up or down to adjust colors on the blueyellow axis.
- To determine the amount required, adjust color shading correction while taking photos of blue sky or a sheet of gray paper.