3 Choose a position for the item and press MENU/OK. The item will be added to "my menu".



- 4 Press MENU/OK to return to the edit display.
- 5 Repeat Steps 3 and 4 until all the desired items have been added.
- My menu" can contain up to 16 items.