
Touch Controls for Focus Zoom

Different touch controls are used during focus zoom (focus check enabled).

Central Area

Tapping the center of the display performs the operations below.



| Mode | Operation performed |
|------|------------------------|
| AF | AF-S: AF |
| | MF : Instant AF |
| AREA | AF-S: AF |
| | MF: Instant AF |
| OFF | AF-S/MF: OFF |

Other Areas

Tapping other areas simply scrolls the display, whether during still photography or movie recording and regardless of the option selected for touch screen mode.

