
Viewing Photo Information-

The photo information display changes each time the focus stick (focus lever) is pressed up.





Zooming in on the Focus Point

Press the center of the focus stick (focus lever) to zoom in on the focus point. Press again to return to full-frame playback.

