

Using the Menus

To display the menus, press MENU/OK.



To navigate the menus:

1 Press MENU/OK to display the menus.



2 Press the focus stick (focus lever) left to highlight the tab for the current menu.



- Press the focus stick up or down to highlight the tab (□, ℍ,
 □, ℍ, □, or ☑) containing the desired item.
- 4 Press the focus stick right to place the cursor in the menu.
- Use the front command dial to select menu tabs or page through menus and the rear command dial to highlight menu items.