

Menu List

Camera menu options are listed below.

Shooting Menus

Adjust settings when shooting photos or movies.



See page 103 for details.

I.Q.	IMAGE QUALITY SETTING	
1/3	IMAGE SIZE	104
	IMAGE QUALITY	105
	RAW RECORDING	106
	FILM SIMULATION	106
	MONOCHROMATIC COLOR	108
	GRAIN EFFECT	108
	COLOR CHROME EFFECT	109
	COLOR CHROME FX BLUE	109
2 ⁄3	WHITE BALANCE	110
	DYNAMIC RANGE	113
	D RANGE PRIORITY	114
	TONE CURVE	114
	COLOR	115
	SHARPNESS	115
	NOISE REDUCTION	115
	CLARITY	116
3 ⁄3	LONG EXPOSURE NR	116
	COLOR SPACE	116
	PIXEL MAPPING	117
	SELECT CUSTOM SETTING	117
	EDIT/SAVE CUSTOM SETTING	118

AF MF	AF/MF SETTING	
1/3	FOCUS AREA	120
	AF MODE	121
	AF-C CUSTOM SETTINGS	122
	STORE AF MODE BY ORIENTATION	126
	AF POINT DISPLAY [1]	126
	NUMBER OF FOCUS POINTS	126
	PRE-AF	127
	AF ILLUMINATOR	127
2 /3	FACE/EYE DETECTION SETTING	128
	AF+MF	130
	MF ASSIST	131
	FOCUS CHECK	131
	INTERLOCK SPOT AE & FOCUS AREA	132
	INSTANT AF SETTING	132
	DEPTH-OF-FIELD SCALE	132
	RELEASE/FOCUS PRIORITY	133
3 ∕₃		133
	TOUCH SCREEN MODE	134
	CORRECTED AF FRAME	137