
## **TALLY LIGHT**

Choose the lamp (indicator or AF-assist) that lights during movie recording and whether the lamp blinks or remains steady.



Option	Description
FRONT OFF REAR	The indicator lamp lights during movie recording.
FRONT OFF REAR <u>o</u>	The indicator lamp blinks during movie recording.
FRONT <u></u> REAR <u></u>	The indicator and AF-assist lamps light during movie recording.
FRONT  REAR OFF	The AF-assist lamp lights during movie recording.
FRONT <u>a</u> rear <u>a</u>	The indicator and AF-assist lamps blink during movie recording.
FRONT <u>a</u> Rear off	The AF-assist lamp blinks during movie recording.
FRONT OFF REAR OFF	The indicator and AF-assist lamps remain off during movie recording.

## ★ WIRELESS COMMUNICATION

This item is also found in the photo menus (1991) 148).