
## Viewing Panoramas-

With the panorama displayed full frame, press the focus stick (focus lever) down to start panorama playback. Vertical panoramas will scroll vertically, horizontal panoramas horizontally.







- In full-frame playback, you can use the front command dial to zoom panoramas in or out.
- Panorama playback is controlled using the focus stick.

	Focus stick (focus lever)	Full-frame playback	Panorama playback	Panorama playback paused
Ī	Up	_	— End playback	
	Down	Start playback	Pause playback	Resume playback
	Left/right	View other pictures	Choose pan direction	Scroll panorama manually