
## Taking Photographs (Mode P)

This section describes how to take pictures using program AE (mode P). See pages 76–85 for information on S, A, and M modes.


1 Slide the STILL/MOVIE mode switch to STILL.



2 Rotate the focus mode selector to S.



3 Rotate the mode dial to P.



- Rotate the mode dial only after pressing the dial lock release to release the dial.
- 4 Confirm that P appears in the display.

